


Lagun Table Assembly

If any parts of the Lagun Tables are missing or damaged, there will be a \$300 charge.

1. Slide open the bed box to the reveal the rectangular slab underneath.



2. Remove the slab and flip over to reveal the parts for the Lagun Table.



3. By using the handles and pressing the button, loosen and slide the leg down to remove the detachable leg for the table.




4. Slide the detachable leg onto the metal mount that

is located on the side of the bed box. Adjust the table height to suit you, and then use the handles to tighten the leg of the table to stay in place.



5. Adjust the piece on the slab to have the hole clear in order to attached to the leg. The slab will be able to move around, and to swivel in and out of the van. Using the handles, tighten the slab to desired position.



6. Once the slab is tight on the leg, the Lagun Table is now fully assembled.

